


Operating Instructions Pedometer Pen

This Pen product contain one Pedometer Counter operate by 1 piece LA44(AG13) battery.

How to operate:

1. Press the button to show the counter  before use.
2. Pedometer Pen should be place or clip on dress pocket upright position. As Fig 1. Counter will start counting while walking.

How to install and Replace battery:

To install or replace battery as Fig 2. Ensure battery are in correct polarity.




How to start writing:

Twist pen lower barrel gentle to extend refill to writing condition and twist back to withdraw writing.



Reference: Table of Standard Calorie Consumption by Walking



Notes:

1. For this precise instrument, please make sure to operate and maintain properly.
2. Don't disassemble the instrument except replacing battery, or will cause damage to it or influence on its measuring accuracy.
3. To maintain accurate reading, the battery should be changed every 12 month. When changing the battery, please call the expert, or maybe cause damage.
4. Breakable does not drop and wet.